



Assembly Guide

E4407 / E4408 Wheelb f. midi. b.tower

E4409 / E4410 Wheelb f. maxi b.tower



E4407/E4409




E4409/E4410

2018.10

First check the contents to make sure that nothing is missing. Sort out the screws and fittings as shown.
Assemble your furniture step by step, as shown in the illustrations.



Assembly Guide



E4407/E4408 - Wheelbase Medium





2018.10


First check the contents to make sure that nothing is missing. Sort out the screws and fittings as shown.
Assemble your furniture step by step, as shown in the illustrations.
















Assembly Top
(Acrylic and shelves not included)



Assembly Guide

E4409 / E4410 Wheelb f. maxi b.tower



2018.10

First check the contents to make sure that nothing is missing. Sort out the screws and fittings as shown.
Assemble your furniture step by step, as shown in the illustrations.

